




# Main Body




2			
Order	Part number	Name_English	Quantity
1	U456-00019	Bumper	1
2	U455-00013	Lock Nut - M6	8
3	U456-00020	Bolt - M6x18	4
4	U456-00021	Chassis	1
5	U455-00009	Bolt - M6x12	4
6	U455-00021	Bearing Holder	2
7	U456-00022	Trailing Flap	1
8	U456-00023	Pivot - Trailing Flap	1
9	U455-00011	Screw - M6x16	2
10	U456-00024	Graduator	1
11	U456-00025	Screw - St4.2x10	5
12	U456-00026	Rear Shield	1
13	U456-00027	Spring - Connecting Rod	1
14	U456-00028	Connecting Rod	1
15	U455-00032	Check Ring	2
16	U455-00029	Washer - M10	2
17	U455-00003	Screw - M5x12	4
18	U455-00004	Tooth Disc	2
19	U455-00006	Lock Nut - M5	4




3			
Order	Part number	Name_English	Quantity
1	U456-00029	Engine Base	1
2	U456-00030	Bolt	3
3	U455-00042	Belt - V10x780	1
4	U455-00039	Key	2
5	U455-00041	Screw - M6x6	1
6	U455-00040	Engine Pulley	1
7	U456-00031	Adaptor	1
8	U456-00032	Bearing	1
9	U456-00033	Wave Washer	1
10	U456-00034	Axle Protection Bracket	1
11	U456-00035	Lock Nut - M14	3
12	U456-00036	Spacer	1
13	U456-00037	Blade	1
14	U456-00038	Spring Washer	1
15	U456-00039	Blade Bolt	1

# Front Axle



4			
Order	Part number	Name_English	Quantity
1	U455-00114	Wheel Cap	2
2	U455-00002	Bolt - M8x16	2
3	U455-00053	Spring Washer - M8	2
4	U455-00061	Washer - M8	2
5	U455-00055	Wheel	2
6	U455-00056	Bearing	4
7	U455-00057	Spacer	2
8	U455-00058	Spacer	2
9	U456-00040	Front Axle	1
10	U455-00059	Spherical Bearing	4
11	U456-00041	Scraper	2


5 Rear axle





5			
Order	Part number	Name_English	Quantity
1	U455-00114	Wheel Cap	2
2	U455-00002	Bolt - M8x16	2
3	U455-00053	Spring Washer - M8	2
4	U455-00061	Washer - M8	2
5	U456-00042	Rear Wheel - 9"	2
6	U455-00056	Bearing	4
7	U455-00057	Spacer	2
8	U455-00058	Washer	2
9	U456-00043	Rear Axle	1
10	U455-00085	E-Clip - M9	2
11	U455-00084	Spacer	4
12	U455-00076	Bearing	4
13	U455-00082	Drive Pinion - R/H	1
14	U455-00079	Ratchet	2
15	U456-00044	Dustproof Shield	2
16	U455-00073	Right Bearing Sheath Assembly	1
17	U456-00046	Right Bearing Sheath	1
18	U455-00075	Dust Seal	2
19	U455-00068	Circlip - M20	2
20	U537-00035	Rear Transmission Partition	1
21	U455-00066	Spherical Bearing	2
22	U455-00078	Check Holder	2
23	U456-00047	Transmission Assembly	1
24	U455-00088	Spring	1
25	U456-00048	Pulley	1
26	U455-00077	Circlip - M12	2
27	U456-00009	Spacer	2
28	UG700-00055	Bolt - M6x20	2
29	U455-00071	Adjustment Lever	1
30	U455-00070	Spring Of Adjustment Lever	1
31	U456-00008	Bolt - M6x14	3
32	U456-00007	Screw - M5x8	2
33	U455-00013	Lock Nut - M6	3
34	U455-00074	Left Bearing Sheath Assembly	1
35	U456-00049	Right Bearing Sheath	1
36	U455-00083	Drive Pinion - L/H	1
37	U455-00080	Spring - Drive Pinion	6
38	U455-00081	Pin - Drive Pinion	6
39	U456-00041	Scraper	2
40	U456-00006	Bearing	2
41	U455-00089	O-ring	2

# 6 Handle And Controls



6			
Order	Part number	Name_English	Quantity
1	U456-00051	Handle	1
2	U456-00011	Handle Sheath	1
3	U455-00092	Clutch Lever	1
4	U455-00093	Opc Lever	1
5	U456-00052	Throttle Control Box Upper Cover	1
6	U455-00013	Lock Nut - M6	3
7	U506-00035	Screw - ST2.9x13	1
8	U506-00036	Throttle Control Grip	1
9	U456-00053	Throttle Control Bracket	1
10	U455-00095	Screw - M6x40	1
11	U506-00038	Screw - M6x50	1
12	U456-00054	Throttle Control Box Lower Cover	1
13	U506-00042	Screw - ST4x18	3
14	U455-00097	Clutch Cable	1
15	U506-00041	Brake Cable	1
16	U456-00055	Throttle Cable	1
17	U456-00012	Cable tie	1
18	U455-00054	Washer - M6	3
19	U506-00048	Hook - Starter Rope	1
20	U455-00120	Axis Pin - 8x25	2
21	U455-00102	Lock Lever	2
22	U455-00101	Connecting Bolt	2
23	U455-00100	Fix Cap	2
24	U455-00104	Spacer	2
25	U455-00105	Spacer	4
26	U455-00106	Tooth Disc Kit	2
27	UAE55-00062	Lock Nut-M8	2